




Joseph Lstiburek, Ph.D., P.Eng, ASHRAE Fellow

Building Science

Foundations




presented by www.buildingscience.com










Mechanisms of Flow




• Liquid	Bulk Capillary Osmosis	Hydrostatic Pressure Concentration Gradient Concentration Gradient
• Vapor	Diffusion Air Transport	Vapor Pressure Air Pressure




Building Science Corporation Joseph Lstiburek – Foundations 5



























Surface Tension: Wettable

Water attracted to surface more than self

$\theta < 90^\circ$

normal material: "wetable"

Water attracted to self more than surface

$\theta > 90^\circ$





hydrophobically treated: "non-wetable"

Building Science Corporation
Joseph Lstiburek – Foundations 39

Capillary Pressures


- Result of surface tension = attraction to surfaces
 - pressure varies with pore size
 - e.g., height rise in a glass tube

Building Science Corporation
Joseph Lstiburek – Foundations 40




Capillary Flow- concrete sucks


Example: Clay or silt
Wicking (dozens - hundreds of ft)



Building Science Corporation
 Joseph Lstiburek – Foundations 45

Building Science Corporation
 Joseph Lstiburek – Foundations 47




Building Science Corporation
 Joseph Lstiburek – Foundations 48

Capillarity + Salt = Osmosis

- Mineral salts carried in solution by capillary water
- When water evaporates from a surface the salts left behind form crystals in process called efflorescence
- When water evaporated beneath a surface the salts crystallize within the pore structure of the material in called sub-efflorescence
- The salt crystallization causes expansive forces that can exceed the cohesive strength of the material leading to spalling

Building Science Corporation

Joseph Lstiburek – Foundations 49



Building Science Corporation

Joseph Lstiburek – Foundations 50

Diffusion + Capillarity + Osmosis = Problem

- Diffusion Vapor Pressure 3 to 5 psi
- Capillary Pressure 300 to 500 psi
- Osmosis Pressure 3,000 to 5,000 psi




Building Science Corporation

Joseph Lstiburek – Foundations 51









Building Science Corporation



Joseph Lstiburek – Foundations 52














Building Science Corporation

Joseph Lstiburek – Foundations 73




Building Science Corporation

Joseph Lstiburek – Foundations 74




Building Science Corporation


Joseph Lstiburek – Foundations 75






Building Science Corporation

Joseph Lstiburek – Foundations 76


















Building Science Corporation

Joseph Lstiburek – Foundations 101



Building Science Corporation

Joseph Lstiburek – Foundations 102




Building Science Corporation


Joseph Lstiburek – Foundations 103



Building Science Corporation

Joseph Lstiburek – Foundations 104







Building Science Corporation

Joseph Lstiburek - Foundations 113



Building Science Corporation

Joseph Lstiburek - Foundations 114



Building Science Corporation

Joseph Lstiburek - Foundations 115



Building Science Corporation

Joseph Lstiburek - Foundations 116

