

### **Building Enclosures**

Dr John Straube
Building Science Corporation
University of Waterloo





### **Building Functions**

- Human needs... more than shelter (e.g. Location, Shelter, Utility, Comfort & Delight)
- ...function of a building:

"Provide the desired environment for human use and occupancy"

"Durability, Convenience, and Beauty"
Vitruvius, 70 BC

Building Science 2008

Enclosures No 2

### **Building Components**

- Buildings are made of several large systems
- The systems that make up a a building can be grouped in four categories
  - Superstructure
  - Enclosure
  - Service Systems
  - Fabric

Building Science 2008


closures No. 3 /

## The Enclosure: An Environmental Separator

- The part of the building that physically separates the interior and exterior environments.
- Includes all of the parts that make up the wall, window, roof, floor, etc... from the innermost to the outermost layer.
- Sometimes, interior partition also are environmental separators (pools, rinks, etc.)

Building Science 2008

Enclosures No. 4



### Importance of the Enclosure

- Image
  - People see it!
- Building problems
  - Often heat, moisture and the enclosure
- Energy consumption
  - Driven by enclosure performance
- Durability often less than building
  - Roof 15-30 yrs, Windows 20-35 yrsSealants 5-25 yrs

Building Science 2008

Enclosures No. 6

### **Enclosure Loadings**

- The separation function generates loads
- Load: any event, phenomenon or characteristic that can affect the enclosure
  - Heat, Air, Moisture
  - Fire, Sound
  - UV, Ozone
  - Gravity, impacts, abrasion
  - Insects
  - Etc...

Building Science 200

Enclosures No. 7 /

### Loads: Climate /

- · Design for
  - Climate zone
  - Site

Seattle ≠ Sacramento Miami ≠ Minneapolis Edmonton ≠ Vancouver


- Building height, shape, complexity

### Marcus Vitruvius Pollio

These are properly designed, when due regard is had to the country and climate in which they are erected. For the method of building which is suited to Egypt would be very improper in Spain, and that in use in Pontus would be absurd at Rome: so in other parts of the world a style suitable to one climate, would be very unsuitable to another: for one part of the world is under the sun's course, another is distant from it, and another, between the two, is temperate.

Building Science 2008

Enclosures No 8/



### Climate Load Modification


- Building & Site (overhangs, trees...)
  - Creates microclimate
- Building Enclosure (walls, windows, roof...)
  - Separates climates
  - Passive modification
- Building Environmental Systems (HVAC...)
  - Use energy to change climate
  - Active modification

Building Science 2008

Enclosures No. 10 /







### **Enclosure Failures**

- Problem causes:
  - 1. Material/system does not fill function
  - 2. Functionality not designed for
  - 3. Not built according to design (workmanship)
- Avoidance requires understanding each

Building Science 2008

\_\_\_\_

### **Five Fundamental Changes**

- 1. Increasing Thermal Resistance
- 2. Changing Permeance of Enclosure Linings
- 3. Water/Mold Sensitivity of Materials
- 4. Hygric Buffer Capacity
- 5. 3-D Airflow Networks

Building Science.com

### 1. Thermal

- Old buildings used energy leakage to dry materials and assemblies
- Increased airtightness
  - Reduces drying, interior RH increases
- Increased insulation = less drying
  - Colder exterior, colder interior
  - Wider swings

Building Science.com

### 2. Permeability

- Low permeance exteriors
  - Metal panels, precast concrete
  - OSB and foam vs skip wood sheathing
- Low permeance interiors
  - Polyethylene, vinyl wall paper
  - Vinyl sheet flooring

Building Science.com

### 3. Water/Mold Sensitivity

- Moisture= mold growth
- Wood products
  - New growth vs old
  - Processing: plywood, OSB, particle board
  - Paper, Veneers
- Finishes
  - Drywall, ceiling tile

iilding Science.com


18

### 4. Hygric Buffer Capacity

- Changing moisture storage
  - Concrete block / terra cotta
  - Rough cut wood / skip sheathing
  - Steel stud with exterior gypsum
- Orders of magnitude!
- Lightweight often low-impact

 Hollow walls Taller buildings

5. Three-D Airflow Networks




### **Five Fundamental Changes**

- 1. Increasing Thermal Resistance
- 2. Changing Permeance of Enclosure Linings
- 3. Water/Mold Sensitivity of Materials
- 4. Hygric Buffer Capacity
- 5. 3-D Airflow Networks


### Basic Functions of the Enclosure

- 1. Support
  - Resist and transfer physical forces from inside and out
- 2. Control
- Control mass and energy flows
- 3. Finish
  - Interior and exterior surfaces for people
- Distribution a building function





### **Basic Enclosure Functions**


- - Resist & transfer physical forces from inside and out
    - Lateral (wind, earthquake)
    - Gravity (snow, dead, use)
    - Rheological (shrink, swell)
    - Impact, wear, abrasion
- - Control mass and energy flows
- - Interior and exterior surfaces for people




# Basic Enclosure Functions Support Resist & transfer physical forces from inside and out Control Control mass and energy flows Rain (and soil moisture) Drainage plane, capillary break, etc. Air Continuous air barrier Heat Continuous layer of insulation Vapor Balance of wetting/drying Finish Interior and exterior surfaces for people











### **Enclosure Design Principles 1**

- · Design a complete structural load transfer path
  - Structure, windows, ties, etc
  - All loads go to ground
- Respect the site and climate
  - Rain, sun, wind, hill, valley, high rise or low-rise
- Continuous rain control plane
  - Control with surface features and detailing
  - Drained, storage, or perfect barrier strategy
- · Continuous plane of air barrier tightness
  - Fastidious attention to detail 3-D

Building Science 2008

inclosures No 31 /

### **Enclosure Design Principles 2**

- Provide a continuous plane of insulation
  - Ideally separate structure from enclosure
  - Avoid thermal bridges
- · Provide a moisture tolerant design
  - Balance wetting, drying, and storage (matl's, climate)
  - Use appropriate levels of vapour control
    - No cold vapor barriers, allow drying
- Accommodate movements and tolerances
- Draw all of the Details!

Building Science 2008

Enclosures No 32./

## Building Enclosure Concept Design Stage Checklist SUPPORT 1. Supplies The Enchanical loads 1. Supplies The Enchanical loads 1. Supplies The Enchanical loads 2. Heat Flow Control (Temperature and Energy) 2. Letter Flow Control (Temperature and Energy) 3. control of a leakage, 4. Control of a leakage, 5. Rain Control 6. Crack/Novement control 7. Control of Active discomfort and summer 8. control of a leakage, 9. control of a leakage, 9. control of a leakage, 1. surface condensation, i.e. thermal bridges, corners, etc. 1. interstitial condensation (summer & winter) by vapour diffusion and air leakage 1. A. R Flow Control 1. Sound and Wishards Control 1. Sound and Wishards Control 1. Sound and Wishards Control 2. special situations, often involved in design decisions (e.g., sound and Wishards Control 3. Surface condensation, i.e. thermal bridges, corners, etc. 4. Interstitial condensation (summer & winter) by vapour diffusion and air leakage 1. A. R Flow Control 1. Sound and Wishards Control 2. special situations, often involved in design decisions (e.g., sound and Wishards Control 3. surface condensation, i.e. thermal bridges, corners, etc. 4. Interstitial condensation (summer & winter) by vapour diffusion and air leakage 1. A. R Flow Control 1. Sound and Wishards Control 2. Sound and Wishards Control 3. Sound and Wishards Control 4. Sound and Wishards Control 5. Rain Control 6. Crack/Novement control 6. Sounds of Wishards, and movement are complementary consider creep, sag. shrinkage, weelling, both mobiture and control wishards and control of the defence of contr

