Stabs, Graphspaces, Desements, and Delog Grade Spaces





Hold and Weter

- · Source
 - -Hold is a water problem
- Fires
 - -No water no mold





Fath Water. and you can

- Find The Hold
- Clean Up The Hold
- Dry The Building
- Make Sure it Decen't Happen Again



Exclude the Water



















The Old Way - Grows Mold







Interior Blanket






PR-0510g: BuildBoston 2005—Slabs, Crawlspaces, Basements and Below Grade Spaces: Avoiding Mold












































New Way - No Mold








Internally Insulated Basement




Externally Insulated Basement



Basement Insulated in the Middle
































© 2005 Building Science Corporation






Finished Floor over Slab on Grade








































PR-0510g: BuildBoston 2005—Slabs, Crawlspaces, Basements and Below Grade Spaces: Avoiding Mold


















PR-0510g: BuildBoston 2005—Slabs, Crawlspaces, Basements and Below Grade Spaces: Avoiding Mold






Basements Connected to Crawl Spaces




























PR-0510g: BuildBoston 2005—Slabs, Crawlspaces, Basements and Below Grade Spaces: Avoiding Mold








PR-0510g: BuildBoston 2005—Slabs, Crawlspaces, Basements and Below Grade Spaces: Avoiding Mold











Rim Joists









Conditioning Unvented Crawlspaces











© 2005 Bui















