

Joseph Lstiburek, Ph.D., P.Eng, ASHRAE Fellow

Building Science



Windows, Glazing and Curtain Walls



www.buildingscience.com



Windows



Building Science Corporation



Joseph Lstiburek 2














































Innies



Building Science Corporation


Joseph Lstiburek 35



Building Science Corporation


Joseph Lstiburek 36






































Building Science Corporation

Joseph Lstiburek 65




Building Science Corporation

Joseph Lstiburek 66

Games People Play

Building Science Corporation

Joseph Lstiburek 67



We assume a window unit is a single layer.

Under this assumption, it does not matter which side of the assembly we establish the ΔP .

Building Science Corporation



Joseph Lstiburek 68



$P_t = P_c + P_w + P_s + P_g + P_v$
 Not all layers equally "tight"
 ΔP across each layer depends on the side of the wall the pressure is induced
 Removing a layer changes everything


Building Science Corporation Joseph Lstiburek 69

$P_t = P_w + P_s$
 is very different than
 $P_t = P_c + P_w + P_s + P_g + P_v$

Building Science Corporation Joseph Lstiburek 70

















Other Stuff

More Frames = More Heat flow

OVERALL WINDOW U-VALUE (U_w)

For fixed window configurations as shown with height (h) equal to width (w).


Spec. one large window rather than many small ones



SEALED UNIT GLAZING TYPE

- A = 6mm clear / 1/2" air / 6mm clear / metal spacer
- B = 6mm clear / 1/2" air / 6mm low-e¹ / metal spacer
- C = 6mm clear / 1/2" argon / 6mm low-e¹ / metal spacer
- D = 6mm clear / 1/2" argon / 6mm low-e¹ / Helima thermally broken spacer
- E = 6mm clear / 1/2" argon / 6mm low-e² / Helima thermally broken spacer
- F = 6mm clear / 1/2" argon / 6mm low-e² / Edgetech Super Spacer[®]

- 1 - low-e coating emittance = 0.10
- 2 - low-e coating emittance = 0.05



Kawneer Isoport 518

Beware Thermal Flanking

- Beware heat flow around window frame





Figure 1: Thermal Flanking

Figure 2: Flanking Reduced

Building Science Corporation

Joseph Lstiburek 87



Building Science Corporation

Joseph Lstiburek 88

