Joseph Lstiburek, Ph.D., P.Eng, ASHRAE Fellow

Building Science

Adventures In Building Science

Things Are Different Energy Efficiency Materials

There Is No Such Thing As A Free Thermodynamic Lunch

Condensation on Ductwork

Condensation on Ductwork Ductwork in Vented Attics and Vented Crawlspaces

Vented and Unvented Attics
Vented and Unvented Crawlspaces


There Is Nothing Wrong With A Vented Attic


There Is Nothing Wrong With A Vented Attic But.....


Houses With Vented Attics Suck Not all the Time.....but.....





























Crawl Spaces











Conditioned Crawlspaces Not Unvented Crawlspaces


Need Supply Air 50 cfm/1000 ft2 of Crawlspace Area


Or


Dehumidification





















































Back to Ducts....











Not Easy To Put Them Inside....













































Map of DOE's Proposed Climate Zones



March 24, 2003

Conditioned Attics Not Unvented Attics





Conditioned Attics Not Unvented Attics Need Supply Air


Conditioned Attics Not Unvented Attics Need Supply Air 50 cfm/1000 ft2 of Attic Conditioned Attics Not Unvented Attics Need Supply Air 50 cfm/1000 ft2 of Attic


Or Dehumidification


Low-Density Open-Cell Foam Is The Problem












- A: Single-layer of adsorbed molecules
- B: Multiple layers of adsorbed molecules
- C: Interconnected layers (internal capillary condensation
- D: Free water in Pores, capillary suction
- E: Supersaturated Regime

Regimes of moisture storage in a hygroscopic porous material

From Straube & Burnett, 2005

SIP Failures

























Step 1

· Remove strip of OSB from each side of ridge




Step 2

- Create air seal with strip of vapor open membrane (tape seams)
- · Vapor open membrane sheet sealed to OSB with acrylic caulk sealant
- Hold vapor open membrane sheet in place with metal strapping



Step 3

· Construct wood ridge vent with 2x2 furring




















An Oops....That Became A Gift....









Failures Lead To Success







































Hygric Buoyancy

Components in Dry Air	Volume Ratio compared to Dry Air	Molecular Mass - M (kg/kmol)	Molecular Mass in Air
Oxygen	0.2095	32.00	6.704
Nitrogen	0.7809	28.02	21.88
Carbon Dioxide	0.0003	44.01	0.013
Hydrogen	0.000005	2.02	0
Argon	0.00933	39.94	0.373
Neon	0.000018	20.18	0
Helium	0.000005	4.00	0
Krypton	0.00001	83.8	0
Xenon	0.09 10 ⁻⁶	131.29	0
Total Molecular Mass of Air			28.97

Components in Dry Air	Volume Ratio compared to Dry Air	Molecular Mass - M (kg/kmol)	Molecular Mass in Air
Oxygen	0.2095	32.00	6.704
Nitrogen	0.7809	28.02	21.88
Carbon Dioxide	0.0003	44.01	0.013
Hydrogen	0.000005	2.02	0
Argon	0.00933	39.94	0.373
Neon	0.000018	20.18	0
Helium	0.000005	4.00	0
Krypton	0.000001	83.8	0
Xenon	0.09 10 ⁻⁶	131.29	0
Total Molecular Mass of Air			28.97

Note Water Vapor (H2O) is 18 Dry Air is 29





Ratios

1:150


1:300


1:600


Conditioned Attics Not Unvented Attics Need Supply Air 50 cfm/1000 ft2 of Attic

Or Dehumidification

Burying Ducts















Vancouver Mold



- A: Single-layer of adsorbed molecules
- B: Multiple layers of adsorbed molecules
- C: Interconnected layers (internal capillary condensation
- D: Free water in Pores, capillary suction
- E: Supersaturated Regime

Regimes of moisture storage in a hygroscopic porous material

From Straube & Burnett, 2005

