

Joseph Lstiburek, Ph.D., P.Eng.
John Straube, Ph.D., P.Eng.

Building Science 2011

Thermal Control:
Insulation & Thermal Bridges



presented by www.buildingscience.com

Why Control Heat flow?

1. Occupant Comfort
2. Control surface and interstitial condensation
3. Save energy, reduce operating cost & pollution
4. Save distribution & heating plant costs (capital)
5. Increase architectural options
6. Decrease load diversity
7. Meet codes and specs

Building Science

Insulation and Thermal Bridges No. 2/65

How to Control Heat Flow?

Modes of heat transfer:

- Radiation
- Convection
- Conduction




Building Science

Insulation and Thermal Bridges No. 3/65

Conduction

- Heat Flow by direct contact
- Vibrating molecules
- Most important for solids



Building Science

Insulation and Thermal Bridges No. 4/65

Thermal Performance

- Thermal Conductivity
 - Symbol is “k” or “λ”
- Conductance
 - $C = k / \text{thickness}$
- Resistance “R-value”
 - $R = \text{thickness} / \text{conductivity}$
- Measures conduction only
- “effective” conductivity includes other modes

Building Science

Insulation and Thermal Bridges No. 5/65



Building Science

No. 6/65

Convection

- Heat Flow by bulk movement of molecules
- Most important for liquids and gases
- Critical for surface heat transfer (e.g convectors, “radiant floors”)
- Windows

Building Science 2008 Insulation and Thermal Bridges No. 765

Radiation

- Heat flow by electromagnetic waves
- Heat radiates from *all* materials, e.g. campfire
- Passes through gases and vacuum (NOT Solid)

Building Science 2008 Insulation and Thermal Bridges No. 765

Radiation

- Important for surfaces, air spaces, voids – e.g. Thermos bottle
- Key for low-e Windows
- Foil faced insulation, radiant barriers only work when facing an air space
- Radiation within *pores* important for high void insulation (e.g., glass batt)
- Emissivity is the measure

Building Science 2008 Insulation and Thermal Bridges No. 965

Forced Convection

- E.g. air flow (forced air furnace)
- Also heat flow from solid to liquid or gas

Building Science 2008 Insulation and Thermal Bridges No. 1065

Trends in materials





- Low density materials insulate better!
- High density materials are structural
- Past – relied on high density (but **thick**) structural materials to control heat, air, and moisture flow

• Wood	R 1.000 / inch
• Clay Straw	R 0.700 / inch
• Old brick	R 0.180 / inch
• Concrete	R 0.070 / inch
• Steel	R 0.004 / inch

Building Science 2008 Insulation and Thermal Bridges No. 1165

- Density vs R-value
- It's the law

Building Science 2008





Changing Needs

- Now and tomorrow
 - Better heat flow control required
 - More environmental concerns re: energy
 - More demanding comfort standards
 - Building materials & finishes are less resistant to condensation (& mold)

Building Science 2008


Insulation and Thermal Bridges No. 21/65

Materials

- Thermal conductivity (& resistance) varies with
 - material type (conduction, radiation)
 - density and pore structure
 - moisture content
 - temperature difference
- Combination of insulation of air + material
- *Still* air is about R6/inch ($k=0.024 \text{ W/mK}$)
- Only gas fills (e.g. HCFC) can improve this

Building Science 2008

Insulation and Thermal Bridges No. 22/65



Building Science

Insulation and Thermal Bridges No. 23/65

Insulation

- A brief survey . . .

Building Science 2008

Insulation and Thermal Bridges No. 24/65

Fibers

- Mineral Fiber Insulation (vs organic fibers)
 - glass fiber
 - rock fiber • rockwool
 - slag fiber
- Glass vs rockwool
 - melts at a much lower temperature
 - has thinner fibers so can use lower density
 - Lower density means more air permeance, less strength, and low volume (less cost and energy) shipping

Building Science

Insulation and Thermal Bridges No. 25/65

Blown/spray fibrous insulation

- Can use cellulose, glass, rockwool
- Net or adhesive holds sprayed fiber in cavity
- fills space and around obstructions
- avoids settling problems?
- May help control convection

- Are NOT vapour barriers

Building Science

Insulation and Thermal Bridges No. 26/65

Cellulose Wall Spray Insulation

- Density 2.5 to 4+ pcf (> 3pcf is recommended)
- R value 3.5 +/- depending on density
- Helps controls convection (higher density=better)
- Can fill irregular cavity spaces
- Settling a concern with low density (< 3pcf)
- Built in moisture concerns (MC? at close in)
- Provides moisture storage
- Controls mold with borate salts (avoid ammonia)
- Is not part of an air barrier system!

Building Science

Insulation and Thermal Bridges No. 27/65



Blown Cellulose

Building Science 2008



Can act as thermal (fire) control layer over foam

Spray Foam

- Primarily polyurethane foam
- open cell (CO₂ blown) e.g., Icynene
 - about R3.7/inch (R13/3.5", R20/5.5")
 - moderate to high vapour permeance (>10 perms)
 - Airtight <0.01 lps/m² @ 75 Pa
- closed cell (gas blown)
 - R6+/inch • **Depends on skin**
 - 1 - 2 US perms (don't need vapour barrier)
 - Airtight <0.01 lps/m² @ 75 Pa

Building Science

Insulation and Thermal Bridges No. 30/65

Spray Foam

- Open cell
 - Most high vapor permeance
 - controls convection / wind washing
- Closed cell
 - air barrier and part vapor barrier
 - excellent air seal in difficult areas!
 - Beware: adhesion and movement/shrinkage cracks
- Both Expensive
- Neither solve air leakage outside of stud cavity

Building Science

Insulation and Thermal Bridges No. 31/65

Great for sealing/insulating difficult complex details



Building Science




- Complete air-vapour-water barrier solution
- Requires transition membranes

Building Science

Residential – Air Sealing, Attics, Basements




Hybrid: Air, thermal



Building Science


Insulation and Thermal Bridges No. 35/65

R40+ roof, fire protection



Building Science

Insulation and Thermal Bridges No. 36/65



Rigid Boards (sheathing)

- Expanded Polystyrene (EPS)
 - R-value of 3.6 to 4.2
- Extruded Polystyrene (XPS)
 - higher R-value, usually 5/inch or higher
 - usually more strength
- Polyisocyanurate (PIC)
 - Highest temp resistance. Long term R6
- all have fire “issues”

Building Science
Insulation and Thermal Bridges No. 38/65



Mineral Fiber Sheathing

- Semi-rigid MFI (mineral fiber insulation)
 - Rockwool and Fiberglass
 - Air permeable
 - Vapor permeable
 - Allows drainage (provides gap)
- R values of 4 to 4.4/inch

Building Science
Insulation and Thermal Bridges No. 41/65





Building Science 2009

65

Structural Insulated Panels

- Advantages
 - Superior blanket of insulation (3.5"=R12, 5.5"=R20)
 - if no voids then no convection or windwashing
 - May seal OSB joints for excellent air barrier system
- Therefore, done right = excellent
- Small air leaks at joints in roofs can cause problems
- Don't get them too wet from rain
 - Low perm layers means limited drying

Building Science


Insulation and Thermal Bridges No. 44/65



**Beware Joints
No vapor barriers**

Insulated Concrete Forms

- Excellent enclosure system
- Concrete acts as air barrier
- No vapor barrier needed
- Expensive, but high performance (R20)



Building Science



Future products

- Vacuum panels: Depends on vacuum
 - R20-30/inch
 - VacuPor (Porextherm)
- Nanogel/aerogel
 - R12-20/inch
 - Aspen Aerogel



Building Science

Insulation and Thermal Bridges No. 47/65

Radiant barriers

- Often misunderstood
- Must have an air space!!! (below slabs?)
- Performance depends on temperature difference
 - better at high temperatures, e.g., roof, South
- Can be useful (R5 or so) if low cost
- Most effective at high temperatures (radiation $\propto T^4$)
 - How reflective is the material over time?
 - Are dust and corrosion avoided?

Building Science

Insulation and Thermal Bridges No. 48/65




How much insulation?

- Regardless of type, use *more*
- Comfort & moisture –
 - **True** R5-10 is usually enough, but
- For energy / environment
 - As much as practical
- Practical constraints likely the limit
 - How much space available in studs?
 - Exterior sheathing of 1.5”/4”
- Increased insulation should reduce HVAC capital as well as operating!

Building Science

Insulation and Thermal Bridges No. 52/65



Building Science


Insulation and Thermal Bridges No. 51/65

But there are Complications

- Add up the R-values of the layers to get the total R-value of the assembly
- **BUT** the actual thermal resistance of an assembly is affected by
 - Air Leakage
 - Thermal Bridges
 - Thermal Mass

Building Science

Insulation and Thermal Bridges No. 52/65




Building Science 2008

R Values


- An effective property including all heat flow modes

Insulation and Thermal Bridges No. 53/65



Building Science




Insulation and Thermal Bridges No. 54/65



The Meaning of R-value


- Thermal Resistance
 - R-value (material property, not system)
 - Thermal Bridging
- Airtightness and Air Looping
 - About 10-40 % of energy loss
- Mass
 - smooths peaks and valleys
 - takes advantage of heat within (sun, equipment)
- Buildability / Inspectability
 - do you get what you spec/design?

Building Science
Insulation and Thermal Bridges No. 56/65




Attics

- Large temp differences in winter & summer (large temp diffs cause probs)
- One side open to air



Thermal mass

- A heat capacitor, stores heat or cold
- Smooths variations
 - Reduces peak loads (Title24)
- Can reduce energy if
 - Daily temps vary above/below interior temp
 - Energy flows can be stored, eg solar energy or office waste heat



It's More Than Insulation!

- Thermal bridges provide shortcut for heat through insulation
- Heat passes through the structural members
- Common offenders
 - Floor and balcony slabs
 - Shear walls
 - Window frames
 - Steel studs

Building Science Insulation and Thermal Bridges No. 64/65








Thermal Bridging





- Steel is 400 times more conductive than wood
- Steel studs are about 40 times thinner

Building Science
Insulation and Thermal Bridges No. 68/65

Wood vs Steel

Building Science
Insulation and Thermal Bridges No. 69/65






Thermal Bridge Examples

- Balcony, etc
- Exposed slab edge,



Cold surfaces where $R < 5$



High RH / Low R




Insulation and Thermal Bridges No. 81/05

Solving Thermal Bridging

- Exterior insulation can solve most thermal bridges
 - Inside works, but hard to cover structural penetrations
- Lower interior RH to stop condensation

Building Science




Insulation and Thermal Bridges No. 82/05




Building Science 2008



All on the exterior






Summary: Heat flow control

- A *continuous* layer of only R5-10 is key
 - Exterior is easiest to get continuous
 - Should provide much more for energy efficiency
- Heat flow control is not just about R-value!
 - Control of airflow
 - Thermal bridging must be managed
 - Thermal mass can play a role
 - Solar Gain can dominate
 - Window area, shading, low SHGC windows
 - Overhangs, light colors for walls and roofs

Building Science
Insulation and Thermal Bridges No. 93/65



Additional Information

Building Science
Insulation and Thermal Bridges No. 95/65

Cast Concrete

- Solid concrete walls
 - Connect to slabs inside
- A serious problem in cold climates
 - Thermal bridge/ little drying
- Best compromise design in hurricane regions
 - Dry to interior

Building Science 2008