
Joseph Lstiburek, Ph.D., P.Eng, ASHRAE Fellow


# Building Science


Adventures In Building Science




#### Freeze-Thaw Damage


Freeze-Thaw Damage
Freezing Temperatures
Water
Susceptible Brick







Susceptible Brick Firing Temperature Vitrification







# Kelvin Equation


$$\ln rac{p}{p_0} = rac{2 \gamma V_{
m m}}{r R T}$$

# Calculating capillary rise





### Capillary rise versus diameter







Surface area vs. particle size From Straube & Burnett, 2005


















































































































































































































## Diffusion + Capillarity + Osmosis = Problem

Diffusion Vapor Pressure

**Capillary Pressure** 

Osmosis Pressure


3 to 5 psi


300 to 500 psi

3,000 to 5,000 psi


































































































































Traditional Lime Stucco Greater than 20 perms
Lime/Portland Cement Stucco 5 to 10 perms
Portland Cement Stucco 1 to 5 perms
Polymer Modification Less than 1










Figure 1c. Gypsum, hydrated from plaster of paris and water, porosity 30 per cent.





Figure 1b. Brick, sintered clay, porosity 40 per cent.




**Ancient Modification Additives** 

**Cow Dung** 


Egg Whites


Pig Blood












































From the US Army Corps Engineers Extreme Frost Penetration (in inches) based on state averages.

